



Lucas Equine Equipment, Inc.

Bolt-Through Handle Installation Instructions

Item Number: 5900-110-US32D
5900-110-US10B
5900-110-US3

- Items Included:
- 1 Pull Handle
 - 2 ¼-20 Machine Bolts
 - 2 Grommets

- Tools Required:
- Drill
 - 5/16 Drill Bit
 - Flat Head Screwdriver
 - Tape Measure
 - Marker

Note: *Mark and drill holes from the front of the door or the handle side.*

1. Locate area for Bolt-Through Handle installation.
2. Mark the location for the top hole.
3. Measure down exactly 8 inches and mark the bottom hole location. You may use a level to ensure the alignment of the hole locations.
4. Drill each hole location with the 5/16 drill bit.
5. Attach the top of the Bolt-Through Handle with one of the included machine bolts and grommet. Do not tighten.
6. Attach the bottom of the Bolt-Through Handle with the remaining included machine bolt and grommet. Tighten both bolts.