



# Lucas Equine Equipment, Inc.

## Floor-Mounted Door Stops & Guides Installation Instructions

Item Number: 5900-047-A

Items Included: • 1 Floor-Mounted Door Stop or Guide

Tools Required: • Drill (Hammer drill for easier installation)

- 1/2 Masonry Bit
- Mallet/Hammer
- Marker

### Floor-Mounted Door Stop

1. Locate the area for installation.
2. With the door in the preferred position (either open or closed), place the Floor-Mounted Door Stop so that it is flush with the outside vertical edge of the door. Mark the hole locations on the floor. See diagram below.
3. Drill both holes with the 1/2-inch masonry bit to a 4-inch minimum depth. The holes should not exceed 4 1/2-inches.
4. Align the stop with the holes and drive into place with a mallet.

### Floor-Mounted Door Guide

1. Slide the door to a closed position. Locate the area for the Floor-Mounted Door Guide. The guide should be in contact with the door at all times. See diagram below.
2. Leaving a minimum of a 1/4-inch gap between the door and guide. Mark the hole locations on the floor.
3. Drill both holes with the 1/2 masonry bit to a 4-inch minimum depth. The holes should not exceed 4 1/2-inches.
4. Align the stop with the holes and drive into place with a mallet.

