



Lucas Equine Equipment, Inc.

Heavy Duty Bridle Hook Installation Instructions

Item Number: 5900-150-BR

Items Included: • Bridle Hook
• 2 Mounting Screws

Tools Required: • Drill
• #3 Phillips Drill Bit
• 3/16 Masonry Bit (required only for mounting in masonry)
• Marker (required only for mounting in masonry)

For Wood or Metal Applications

Note: For wood or metal tube applications, no pre-drilling is required. However, in metal a 1/8-inch pre-drilled hole may make installation easier.

1. Locate area for bridle hook installation
2. Using drill and #3 phillips drill bit, hold the bridle hook with one hand and secure with one #14 wood screw or tek screw. Make sure the hook is straight and level, and then proceed with the second screw.

For Masonry Applications

1. Locate area for bridle hook installation.
2. Determine hole locations and mark with marker. Make sure holes are straight and level.
3. Set hook aside and pre-drill holes with 3/16 masonry bit at marked locations.
4. Using drill and #3 phillips drill bit, hold the bridle hook with one hand and secure with one (1) masonry tapcon screw. Proceed with the second screw.

Lucas Equine Equipment, Inc • 4161 US Highway 27 South • P.O. Box 158 • Cynthiana, KY 41031 • 888-577-6920 • info@LucasEquine.com • www.LucasEquine.com
(1/10)