



# Lucas Equine Equipment, Inc.

## Shoe Stop with Removable Plate Installation Instructions

Item Number: 5900-047-B

Items Included: • 1 Shoe Stop with Plate  
• 2 #14 Screws

Tools Required: • Drill  
• #3 Phillips Bit  
• 3/16 Masonry Bit  
• Marker

1. Locate the area on the ground where you would like to install the Shoe Stop.
2. Adjust the Shoe Stop so that the thickness of the door is centered within the width of the Shoe Stop, and mark the screw hole locations.
3. Pre-drill hole with a 3/16 masonry bit.
4. Secure the Shoe Stop with one enclosed screw.
5. Ensure that the door is centered within the shoe stop and not touching any part of it.
6. Pre-drill the remaining screw hole and secure with screw.

Lucas Equine Equipment, Inc • 4161 US Highway 27 South • P.O. Box 158 • Cynthiana, KY 41031 • 888-577-6920 • [info@LucasEquine.com](mailto:info@LucasEquine.com) • [www.LucasEquine.com](http://www.LucasEquine.com)  
(1/10)