



Lucas Equine Equipment, Inc.

Standard Door Glide Installation Instructions

5900-030

Items Included: • 1 Standard Door Glide
• 4 #14 Screws

Tools Required: • Drill
• #3 Phillips Bit
• 3/16 Masonry Bit

Notes: *For wood or metal tube applications, no pre-drilling is required. However, in metal a 1/8-inch pre-drilled hole may make installation easier.*

1. Select area for Door Glide installation. It is generally recommended to mount the Door Glide close to the floor on the stall front or the wall, in a position where the door will be in contact with the Door Glide in both the open and closed positions.
2. If mounting into masonry, mark the hole locations and pre-drill with a 3/16 masonry bit.
3. Secure with one of the enclosed screws.
4. Make sure the Door Glide is straight and does not interfere with door operation.
5. Secure with remaining screws.

Lucas Equine Equipment, Inc • 4161 US Highway 27 South • P.O. Box 158 • Cynthiana, KY 41031 • 888-577-6920 • info@LucasEquine.com • www.LucasEquine.com
(1/10)