



# Lucas Equine Equipment, Inc.

## Shoe Guide Installation Instructions

Item Number: 5900-047-A

Items Included: • 1 Shoe Guide  
• 2 #14 Screws

Tools Required: • Drill  
• 3/16 Masonry Bit  
• #3 Phillips Bit  
• Marker

1. Locate the area for Shoe Guide installation, preferably at the edge of the door opening.
2. Position the Shoe Guide so that the door is in the center of the guide, without the Guide touching the door. Mark the first hole location.
3. Pre-drill one hole with the 3/16 masonry bit and secure with one of the enclosed screws.
4. Check for proper alignment. The Shoe Guide should be straight and not touching the door.
5. Mark and pre-drill the remaining screw hole.
6. Secure with remaining enclosed screw.

Lucas Equine Equipment, Inc • 4161 US Highway 27 South • P.O. Box 158 • Cynthiana, KY 41031 • 888-577-6920 • [info@LucasEquine.com](mailto:info@LucasEquine.com) • [www.LucasEquine.com](http://www.LucasEquine.com)  
(1/10)