

Lucas Equine Equipment, Inc.

Wall-Mounted Door Stop/Guide Installation Instructions

Items Included: • 1 Wall Mounted Stop/Guide

• 3 #14 Screws

Tools Required: • Drill

• #3 Phillips Bit

Item Number: 5900-038

Notes: For wood or metal tube applications, no pre-drilling is required. However, in metal a 1/8-inch pre-drilled hole may make installation easier.

For Door Stop Applications

- 1. Locate the area for Wall-Mounted Door Stop installation.
- 2. With the door in the preferred position (either open or closed), place the Wall-Mounted Door Stop on the wall approximately 1/2-inch from the bottom of the door. The stop should be flush with the outside vertical edge of the door.
- 3. Holding the Wall-Mounted Door Stop in position, secure with one enclosed screw.
- 4. Make sure the Wall-Mounted Door Stop is straight and secure with remaining screws.

For Door Guide Applications

- 1. Locate the area for Wall-Mounted Door Guide installation.
- 2. Slide the door to the open position and place the guide flush against the edge of the wall at the left side of the door opening (for doors that slide to the left to open) or flush against the edge of the wall at the right side of the door opening (for doors that slide to the right to open.) Make sure to leave a minimum of 1/4-inch gap between the bottom of the door and the top of the guide.
- 3. Holding the Wall-Mounted Door Guide in position, secure with one enclosed screw.
- 4. Make sure the Wall-Mounted Door Guide is straight and secure with remaining screws.

Lucas Equine Equipment, Inc • 4161 US Highway 27 South • P.O. Box 158 • Cynthiana, KY 41031 • 888-577-6920 • info@LucasEquine.com • www.LucasEquine.com



